3M

Environmental Fate and Effects of Fluorochemicals

Dr. Robert D. Howell
Senior Environmental Engineer
Environmental Science & Assessment Group


Environmental Laboratory


3M

Environmental Issues of Fluorochemicals

- · What are "fluorochemicals"?!?!
- · How are they made and used?
- · What are the environmental issues?
- · What has been done to address the issues?
- What are we doing now to address the issues?
- Where are we going from here?

1





31

Electrochemical Fluorination Cell Products

Desired Product: Perfluorooctanesulfonyl Fluoride (POSF, FX-8)

CF1CF2CF2CF2CF2CF2CF2CF2SO2F

Also Get-

· Other Straight Chain Perfluoroalkyl Products of Various Chain Leng hs

C₆F₁₃SO₂F C₇F₁₅SO₂F C₉F₁₉SO₂F etc. C₀F_{2n+1}SO₂F

· Branched Chain Perfluoroalkyl Products of Various Chain Lengths

CF₂ CF₃ CF₂ CF₃CF₂CF₂CF₂CFCF₂SO₂F CF₃CFCF₂CFCF₂SO₂F

· Other Straight Chain, Branched, and Cyclic Perfluoroalkyl Compounds


CF4 C2F8 C3F8 C4F10 C5F12 F CF3CFCF2CH3

Tars* and Other By-Products Such As SF₆

Environmental Laboratory

3M

Fluorochemical Products & Intermediates



R.A. Guenthner, R.A. and Vietor, M.L. Surface active materials from perfluorocarboxytic and perfluorosulfonic acids. *I&EC Product Research and Development* 1 (1962) 165-169.



Example: Surfactant used in AFFF Products

Three Major Components

"L-4640"

"Diadduct"

· Perfluoro Moiety Primarily Six Carbons Long

Environmental Laboratory

3M

Electrochemical Fluorination Cell Products - Issues

- · Mixtures of Unknown Composition
 - ~80% straight chain
 - ?% branched of same chain length
 - ?% straight chain of different length
 - ?% branched chain of different chain lengths
- Lot-to-Lot Variability in Composition
 - by cell run
 - by location (Antwerp ≠ Cordova ≠ Cottage Grove ≠ Decatur)
- What Do You Test?
 - Products as they are sold?
 - Specific compounds extracted from the mixture?
 - Do you test the impurities? Which ones?

3M

Nomenclature An Enormous Issue

- Experimental Chemical
 - "L-4640" for AFFF
 - "L-1223" for general surfactant use (e.g. cleaning products)
- MSDS
 - Group Number 04-6084-0; 3M ID 98-0211-5617-3
 - "Amphoteric Fluroalkylamid Derivative Trade Secret"
- Toxicology Services
 - T-2816
- PMNs "PMN Substance"
- Chemical Abstracts Service Registry Number
- · Product Development Lab
 - "Acrylic Foamer" or "The Foamer" or "New Foamer" or "Old Foamer"
- · Environmental Laboratory
 - Use "L-Number"
 - May use Environmental Laboratory "Lab Request Number"

Environmental Laboratory

3M

Environmental Issues of Fluorochemicals

- Halogenated
- Persistent
- · Widely Dispersed in the Environment
- Potential to Bioaccumulate
- · Biologically Active


3M

Atmospheric Issues


Extensive Program to Evaluate Atmospheric Fate and Effects of 3M Fluorochemicals as CFC and Halon Replacements


- Experimental
 - IR Spectra
 - UV Cross Sections
 - Hydroxyl Radical Reactivity
 - Singlet Oxygen Reactivity
- · Data Analysis
 - Radiative Effects
 - Global Warming Potential

| Environmental Laboratory | 3M |
|--|--------------------|
| Atmospheric Is | sues |
| CFC and Halon Replacement | t Candidates |
| C ₄ F ₁₀ | |
| C ₅ F ₁₂ F: | 2C CF ₂ |
| C ₆ F ₁₄ | CF3 |
| C ₄ F ₉ C ₄ F ₉ F ₂ C | FCC4F9 |
| | |
| | |



Environmental Laboratory **3M** Atmospheric Issues of Perfluorinated Compounds Ozone Depletion Potential CFC-11 = 1Perfluorochemical = 0 CFC-113 = 0.81,1,1-TCE = 0.1 Atmospheric Lifetime Perfluorochemicals = 5,000 years 1,1,1-TCE = 5.4 years **Global Warming Potential** $CO_{2} = 1$ $n-C_4F_9OCH_3 = 300$ $C_5F_{12} = 4,100$ $C_6H_{14} = 7,400$ CFC-11 = 4,0001,1,1-TCE = 110





3M

Research at Michigan State University

Dr. Craig Criddle Blake Key

NSF Center for Microbial Ecology and
Department of Civil and Environmental Engineering


Environmental Laboratory

3M

Research at Michigan State University

Multichamber Microcosms

- Fermenting
- Acetogenic
- Methanogenic
- Sulfidogenic
- Denitrifying
- Aerobic



| Research at Michigan State University | | | |
|---------------------------------------|--|------------------|--|
| Fluorinated Sulfonates | CH ₂ FSO ₃ CHF ₂ SO ₃ CF ₃ SO ₃ CF ₃ CH ₂ SO ₃ CF ₃ CF ₂ CF ₂ CF ₂ CF | | |
| Fluorinated Carboxylates | CH₂FCOO' CHF₂COO' | CF3COO. | |
| Fluorinated Sulfonamide | CF3CF2CF2CF2CF2CF2CF2CF | O CH₂CH₃ F₂SN | |
| CAS 2991-51-1 | 7 | | |
| N-ethyl-N-[(hep | otadecafluorooctyl)suifonyl]-glycine p | otassium salt | |

3M

Recent Results

At MSU: Aerobic and Anaerobic Systems

$$CH_2FCO_2$$
 and CHF_2CO_2 $F' + CO_2 + H_2O$ $CF_3CH_2SO_3$ and $nF' + 7 + 7 + CO_2 + H_2O$ $C_3F_{17}CH_2CH_2SO_3$

- · several volatile degradation products
- fluoride released concentration dependent

At USGS in Mento Park, Calif.: Anaerobic Systems

 CF_3CO_2 \longrightarrow CHF_2CO_2 \longrightarrow CH_2FCO_2 \longrightarrow CH_3CO_2 \longrightarrow CH_4


Environmental Laboratory

3M

Light Water™ AFFF Usage Wastes

- Continuing Issue with Customers
 - Fire Fighting Training Sites
 - Fire Protection Equipment Testing
 - Accidental Discharge by Automatic Equipment
 - Simple Operation and Maintenance Required
- Potential Environmental Harm
 - Fish Kills
 - Bird Exposure
 - Disruption of Wastewater Treatment Plants
- Potential Negative Publicity for the Corporation

Major Components of 3M AFFF Products 1% "Filmer" FC-95 C₈F₁₇SO₃ 3% "Acrylic Foamer" L-4640 C₆F₁₃SN C₃H₆N(CH₃)₂ H 20% Butyl Carbitol C₄H₉OC₂H₄OC₂H₄OH 8% Octyl Sulfate C₈H₁₇OSO₃



3M

AFFF Waste Treatment

- 1. Addition of Cationic Polyelectrolyte
- 2. Flocculation
- 3. Separation

Precipitation

Centrifugation

Sand Filtration

Reverse Osmosis/Ultrafiltration


- 4. Discharge of Treated Water
- 5. Disposal of Polymer/Surfactant Precipitate Incineration


 Landfill

Environmental Laboratory












14







| Environmental Laboratory | | 3M | |
|-----------------------------------|-------------------------------------|----------------|--|
| Fluorochemical Surfactant Removal | | | |
| L-4640 | Concentration in Supernatant (mg/L) | Removal (%) | |
| Naico 8157 | 4.9 | 99.4 | |
| Naico 7735 | 3.4 | 99.6 | |
| FeCl ₃ | 2.2 | 99.7 | |
| FC-95 | | | |
| Naico 8157 | 0.67 | 99.8 | |
| Naico 7735 | 0.02 | 99.9 | |
| FeCl ₃ | 0.00 | 100.0 | |

3M

Future Work on AFFF Waste Treatment

Separation Method

Is precipitation sufficient?
Centrifugation, sand filtration?
Reverse osmosis/ultrafiltration: too costly, difficult to operate and maintain.

Disposal of Polymer/Surfactant Precipitate

Incineration of fluorochemicals?
Landfill possible?

Seeking Wastewater Treatment Firm for Scale-up

Environmental Laboratory

3M

Fluorochemical Bioconcentration in Fish

Uptake Experiment

25 mg/L ammonium perfluorooctanoate (FC-143)

30 fish/tank


5 fish removed and sacrificed at day 7 and day 13


Analysis by combustion and F analysis by ISE

Depuration Experiment

Fish remaining at end of uptake put into fresh water

5 fish removed at day 14, day 17, and day 20 Analysis by combustion and F analysis by ISE







Fluorochemical Bioconcentration in Fish

Accomplishments

- Developed method for fluorochemical concentration in fish by combustion method
- FC-143 report reviewed by Dr. John Glesey, Environmental Toxicology Dept., Michigan State University
- · Incorporated recommendations into protocol
- Presented results to customer and at SETAC 1995.

Future Work

- FC-95 (perfluorooctane sulfonate)
- · Acrylic foamer (L-4640)
- · Ethyl FOSE alcohol
- · Others as necessary

Environmental Laboratory

3M

Fluorochemical Products - Issues

- · Analytical Procedures are Extremely Difficult
 - Hindered by the number of components
 - Techniques/methods valid for one component probably won't work for other components
 - Charged vs. uncharged
 - · Positive charge vs. negative charge vs. zwitterionic/amphoteric
 - What matrix?
 - · Soil sand, clay, loam, compost, ...
 - · Water sewage sludge, wastewater, drinking water, sea water, groundwater, ...
 - · Animal · rabbit, rat, human, fish, cockroach, ...
 - · Tissue blood, liver, skin, hair, ...
 - Food pizza, popcom, food simulating liquid, ...
 - · Plant com, algae, ...
 - Atmosphere
 - Product

3M

Fluorochemical Products - Issues

- · Analysis of Fluorochemicals in Environmental Samples NOT Impossible
- Tremendous Developments Since ~1993
 - Extraction Techniques
 - Separation Techniques
 - GC, HPLC, Supercritical Fluid Extraction, and many others
 - Detection Techniques
 - · Mass Spectrometry, FID, PID, FTIR, and many others
 - Automated Sample Handling and Instrument Control to Maximize Throughput
- GLP Methods in Place for Several Fluorochemicals in Several Matrices
 - Including blood, livers, skin, and other animal tissues
- Non-GLP Methods in Place for Several Fluorochemicals in Several Matrices
 - Wastewater sludge, soil, drinking water, air, and others
- · Can Detect Any Fluorochemical in Any Matrix

Environmental Laboratory

3M

Fluorochemical Products - Issues

- · Tremendous Quantities of Fluorochemicals Being Produced
 - Tens or hundreds of millions of pounds/year
 - Don't know production quantities of competitors
 - Don't know their chemistries
- · Effects on Biosphere Unknown
 - Human health?
 - Other living creatures?
- · Human Health and Environmental Studies are
 - Extremely Difficult
 - Extremely Expensive
- · Ultimate Environmental Fate Unknown
- Unknown Liability



Fluorochemical Products - Issues

- Product Composition
 - Unknown
 - Not Critical to Product Use
- · Products meet certain QC specifications
 - Boiling Point (Fluorinert Products)
 - Surface Tension (Fluorad Products)
 - Oil & Water Repellancy (Scotchban & Scotchgard Products)
 - Extinguishment (Light Water Products)
 - Other physical/chemical properties as appropriate to meet specifications
- End Use May Be Unknown
 - Don't know who buys them
 - Don't know what kinds of products they are used in

Environmental Laboratory

3M

Fluorochemical Steering Committee

Charles Cowman Specialty Chemicals Division

Thomas Dipasquale Legal

Craig Olson Chemical, Film and Allied Group Compliance

Sik-Toh Ting Fluorochemical Technology Center

Paul Ackerman Specialty Materials Division

Larry Zoebel Medical Department

John Butenhoff Toxicology Services

Dale Bacon Environmental Laboratory

James Sugg Industrial Hygiene Services
Don Theissen Corporate Product Responsibility

Lael Pickett Specialty Chemicals Division
Craig Burton Fluorochemical Technology Center

3M

Fluorochemical Technical Advisory Committee

Craig Burton

Fluorochemical Technology Center

Craig Olson

Chemical, Film and Allied Group Compliance

Jim Johnson

Environmental Laboratory

Roger Perkins Steve Gordon

Toxicology Services Toxicology Services

Jeff Mandel

Medical Department

Robert Howell John Marhevka Stan Sorenson

Environmental Laboratory Corporate Research Laboratory

Industrial Hygiene Services

V. Prothapragada

Specialty Materials Division

Environmental Laboratory

ЗМ

Fluorochemical Work in Progress

- New Product Testing (Evaluate 2/week & Test 3/month)
- PMNs (2 4/year)
- · Water Solubility (e.g. Ethyl FOSE Alcohol)
- FC-129 Degradation Study
- HFE 401 & HFE 402 Fish, Daphnia, Algae
- Michigan State Research Biodegradation
- FC-845 Process Wastewater Ecotox (Daphnia & Fish)
- Method Development Ongoing for different compounds and matrices
- Pesticide Working Group
- Bioconcentration (FC-143, FC-95, Ethyl FOSE, and others)
- GLP Tox Studies Underway (e.g. Dermal Transport)
- Degradable Fluorochemical Building Blocks
- · Proposals
 - Soil Sorption
 - Comparison of Extinguishment with AFFF vs. Non-Extinguishment